


10. DISCHARGE VALVE COVER ASSEMBLY (1ST STAGE)



All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.

10. DISCHARGE VALVE COVER ASSEMBLY (1ST STAGE)

No.	Description	Ref Part No.	QTY
-	Discharge valve Cover Assembly (First Stage)	1901800812	1
1	Discharge Valve Lantern Cover	1903718903	1
2	O ring (R49, ID 104.14 x D5.33)	0663211205	1
3	Copper Gasket (ID 118 x D111.2x2)	0653050049	1
4	Discharge Valve	1901003122	1

Note :

Discharge Valve Cover Assembly First Stage - Qty. : 04nos. per Compressor